- DO NOT CUT, DRILL, NOTCH, OR OTHERWISE DAMAGE TRUSSES. Contact your BFS Representative for assistance PRIOR TO modifying any truss. Espanol (NO CORTE, PERFORE, HAGA MUESCAS O DANE DE CUALQUIER OTRA MANERA LAS TRUSSES (CERCHAS DE MADERA). Contacte a su representante de BFS para asistencia ANTES de realizar cu alquier modification.
- realizar cualquier modification.)


 1. This Truss Placement Diagram is intended to serve as a guide for truss installation. This Diagram has been prepared by a Truss Technician and is not an engineered drawing.

 2. The responsibilities of the Owner, Building
- The responsibilities of the Owner, Building Designer, Contractor, Truss Designer, and Truss Manufacturer shall be as defined by the TPI 1 National Standard.
- The wood components shown on this diagram are to be used in dry service (moisture content<19%) and non-toxic environmental applications. The metal plates and hangers are galvanized to the G60 Standard unless noted otherwise.
- Refer to the Truss Design Drawings for specific information about each individual trust design.
- design.
 5. The Truss Technician shall provide Truss-to-Truss Connection Requirements. Any special or other connection shall be the responsibility of the Building Designer.
- 6. The Truss Placement Diagram and Truss Design Drawings are the property of Builders FirstSource and may not be reused or reproduced in part or in total under any circumstances without prior written authorization.
- 7. In some cases, field framing may be required to achieve the final appearance shown on the Construction Documents.
- 8. Field framing, including valley rafters, installed over roof trusses shall have a knee brace from the rafter to the truss top chord at intervals of 48" on center (O.C.) or less. Stagger knee braces from adjacent rafters such that the load is distributed uniformly over multiple truss locations and not concentrated at one location or along one truss.
- anny one turns Top Chords shall be fully sheathed or have lateral bracing (purlins) spaced at 24" O.C. or less. Truss Bottom Chord Bracing shall not exceed the maximum shown on the Truss Design Drawing. Field framed bottom chord floor or ceiling attachments shall be spaced at 24" O.C. or less. Proper Bracing prevents buckling of individual truss members due to design loads.
- 10. This Placement Diagram is based upon the supporting structure being structurally adequate, dimensionally correct, square, plumb, and level to adequately support the trusses. The foundation design, structural member sizing, load transfer, bearing conditions, and the structure's compliance with the applicable building code are the responsibility of the Owner, Building Designer, and Contractor.

 11. If Piggyback Trusses are included in this
- If Piggypack Trusses are included in this project, refer to the Mitek Piggyback Connection Detail applicable for the project details and wind load category.
 The Contractor shall follow the SBCA TTB.
- 12. The Contractor shall follow the SBCA 11B Partition Separation Prevention and Solutions for truss attachment to non-load bearing walls and carefully complete these details to avoid gypsum wall board related issues. WARNING:
- TRUSSES MUST BE BRACED DURING
 INSTALLATION. FAILURE TO DO SO MAY
 RESULT IN INJURY OR DEATH. Espanol (TRUSSES (CERCHAS) DEBERAN TENER UN
 SOPORTE DURANTE LA INSTALACION. NO
 HACERLO PODRIA RESULTAR EN LESIONES O
 MUERTE.)

 1. Trusses shall be installed in a safe manner
- meeting all code, local, OSHA, TPI, and BCSI Specifications. Failure to follow these specifications may result in injury or death. 2. Buildings under construction are vulnerable to high winds and present a possible safety
- buildings under constitution are vunierable to high winds and present a possible safety hazard. The Contractor is responsible for recognizing adverse weather conditions and shall take appropriate action to prevent injury or death.
- Geam:
 3. BCSI INSTRUCTIONS SHALL BE FOLLOWED:
 BCSI-B1 = Safe Truss Handling and Installation
 BCSI-B2 = Installation and Temporary Restraint
 BCSI-B3 = Permanent Restraint
 BCSI-B4 = Safe Construction Loading
- BCSI-B4 = Safe Construction Loading BCSI-B5 = Truss Damage and Modification Guidelines
- BCSI-B7 = Floor Truss Installation BCSI-B8 = Toe-Nailed Connections BCSI-B9 = Multi-Ply Girders
- BCSI-B9 = Multi-Ply Girders
 BCSI-B10 = Post Frame Truss Installation
 BCSI-B11 = Fall Protection
- 4. Follow TPI Requirements for Long Span Trusses (>60').





HANGER


H2.5A


SDWC15600

LTHJA26

LUS24

HUS26





EVERSTEAD SHOP DRAWINGS/SUBMITTAL REVIEW

SUBMITTAL WAS REVIEWED FOR DESIGN CONFORMITY AND GENERAL CONFORMANCE TO CONTRACT DOCUMENTS ONLY. THE CONTRACTOR IS RESPONSIBLE FOR CONFIRMING AND CORRELATING DIMENSIONS AT JOBSITE FOR TOLERANCE, CLEARANCE, QUANTITIES, FABRICATION, COORDINATION OF HIS OR HER WORK WITH OTHER TRADES, AND FULL COMPLIANCE WITH CONTRACT DOCUMENTS.

STATUS:

APPROVED

08/03/2021

REVIEWED BY:

BH

ENGINEER, EVERSTEAD

DESIGN LOADS:

25 PSF TCLL 20 PSF TCDL 10 PSF BCDL

D PERMANENT BRACING FOR HOLDING FEAL FORCES SHALL BE DESIGNED AND FHAN THE INTALLES ARE TO BE APPLIED OF ASTENING IS COMPLETED. AT NO TIME HAN DESIGN LOADS BE APPLIED TO THE CCTIONS ARE RECOMMENDATIONS ONLY ING DESIGNER. TRUSSES ARE CAPABLE OF

PROPER HANDLING OF TRUSSES SHALL BE THE RESPONSIBE CREW AT THE JOBSTIE. TEMPORARY AND PERWANENT TRUSSES PLUMB AND FOR RESISTING LATERAL FORCES SINSTALLED BY OTHERS. NO LOADS OTHER THAN THE INTA TO TRUSSES UNTIL AFTER ALL BRACING AND FASTENING IS SHALL CONCENTRATED LOADS GREATER THAN DESIGN LY TRUSSES. ALL TRUSS TO FRAMING CONNECTIONS ARE READLY SEED TO BE SPECIFED BY THE BUILDING DESIGNER.

AND NEED TO BE SPECIFED BY THE BUILDING DESIGNER.

BuildersFirstSource



JOB No. 2880703	DESCRIPTION SU	JOB ADDRESS	CITY	DESIGNER Scott Clevenger	DATE 7/27/2021
	SUMMIT HOMES - WOODSIDE RIDGE #30				

ROOF TRUSS LAYOUT

PAGE

1 of 1