

REFER TO PROVIDED BSCI-B1 BRACING SUMMARY SHEET FOR TEMPORARY, PERMANENT AND GABLE END BRACING

## **UPLIFT RESISTANCE:**

All trusses are to be held down with (1) TLOK06 screw or (1) RT clip per ply, at each bearing location unless noted otherwise on this diagram