20300 W 207TH St
Spring Hill, KS 66083

PREMIER
BUILDING SUPPLY OF KANSAS CITY

Phone: 913.686.1812
www.premierbuildingsupply.com

Customer
Clover & Hive

Job Name:
Marmalade - Farmhouse

Address:
2134 SW Rutherford Dr

Salesperson:
Kyle Clifford

Designer:
Anthony

ROOF TRUSS PLACEMENT DIAGRAM

NTS

P230371

7/3/2023

- EL EXTREMO IZQUIERDO DE LOS TRUSSES (VEA LOS PERFILES)

TODAS LAS DIMENSIONES PARA LAS TRUSSES SON DE FUERA DE LA MADERA (u.n.o.)

ESTABLECER LOS TRUSSES NIVELADAS CON LA ESTRUCTURA (u.n.o.)

- LEFT END OF TRUSS (SEE TRUSS PROFILES)

ALL ROOF TRUSS DIMENSIONS ARE FROM OUTSIDE EDGE OF STUD (u.n.o.)
SET ROOF TRUSSES FLUSH WITH FRAMING (u.n.o.)

WARNING: Trusses must be handled with care to prevent damage and injury.

This truss placement diagram is to be used only as an installation aid; it is not a structural diagram. These trusses are designed as individual building components to be incorporated into the building design at the the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing.

Professional advice should be sought regarding handling, installation, temporary and permanent bracing before erecting trusses. Temporary and permanent bracing is required during installation of trusses to prevent possible collapse.

For general guidance regarding bracing, consult "BCSI-06" available jointly from WTCA & TPI.

Premier Building Supply must be notified of any issues requiring a back charge prior to any work being done. Premier Building Supply reserves the right to use it's service staff in lieu of being back charged.

36-00-00 B4 <u>M</u> VC4 42-00-00 VE2 VC<sub>1</sub> VE1 C3 CL 1-11-04 \*\* EDGER CONNECTION S C3 E2 C2 72 E1 C2 ¥==¥===== 1-10-12 SLOPED CLG.

FLAT

@ 11'

SLOPED CLG. 5-10-00 C2 C2 -11-04 1-00-00 WALL RAKED TO BOTTOM OF D1 D1 7-00-00 14-00-00 6-06-00 8-06-00 36-00-00

1 - SDWC 15600 REQUIRED AT ALL BEARING LOCATIONS (u.n.o.)

ALL TRUSS TO TRUSS CONNECTIONS = 'NAILED" (u.n.o.)

1 - SDWC 15600 NECESARIO EN TODO LOS PUNTOS DE APOYO (u.n.o.)
TODAS LAS CONEXIONES DE TRUSS A TRUSS = 'CLAVADAS " (u.n.o.)

HANGER SCHEDULE		QUANTITY
	LUS24	3
•	LUS26	0
	HUS26	14
	HHUS26-2	0
	HGUS26-2	0
	HGUS28-2	0
	THJA26	0
	TJC37	0
	THJU26	0
0	HUS28	0
	HUS28-2	0
0	HHUS210-2	0
<u> </u>	HHUS28-2	0
	LUS28	0
	SUL24	0
	SUL26	0
	SUR24	0
	SUR26	0
	THA422	0
	THA426	0
0	THAC422	0
	THAC426	0
	THASL29	0
$\triangle$	THASR29	0
	TBE4	0
	TBE6	0
	SDWC15600	70



ROOF PITCH FRONT TO BACK: 8/12, 4/12 SOFFIT DESIGNED FOR 12" O.H HEEL HEIGHT: 10", 12"

ROOF PITCH LEFT TO RIGHT: 10/12 SOFFIT DESIGNED FOR 12" O.H

HEEL HEIGHT: 12"

ROTATE ATTIC ACCESS TO ALIGN WITH TRUSS DIRECTION.

SEE PLACEMENT PLAN FOR ADDITIONAL INFORMATION

ALL CEILINGS ARE FLAT UNLESS OTHERWISE NOTED