

20300 W 207TH St
Spring Hill, KS
66083

PREMIER

BUILDING SUPPLY OF KANSAS CITY

Phone: 913.686.1812
www.premierbuildingsupply.com

Since 1923

Customer
Clayton Properties

Job Name:
Wildflower - Transitional 3 Car

Address:
1605 SW Buckthorn Dr. HR Lot 204

Salesperson:
Kyle Clifford

Designer:
Michael Dueker

Date:
3/11/2024

Job #:
P240212

Scale:
NTS

ROOF TRUSS PLACEMENT
DIAGRAM

EVERSTEAD
SHOP DRAWINGS/SUBMITTAL REVIEW

SUBMITTAL WAS REVIEWED FOR DESIGN CONFORMITY AND GENERAL CONFORMANCE TO CONTRACT DOCUMENTS ONLY. THE CONTRACTOR IS RESPONSIBLE FOR CONFIRMING AND CORRELATING DIMENSIONS AT JOBSITE FOR TOLERANCE, CLEARANCE, QUANTITIES, FABRICATION, COORDINATION OF HIS OR HER WORK WITH OTHER TRADES, AND FULL COMPLIANCE WITH CONTRACT DOCUMENTS.

STATUS:
APPROVED
03/15/2024

REVIEWED BY:
HCJ

ENGINEER, EVERSTEAD ENGINEERING & DESIGN LLC.

HANGER SCHEDULE		QUANTITY
LUS24		0
LUS26		10
HUS26		0
HHUS26-2		0
HGUS26-2		0
HGUS28-2		0
THJA26		2
TJC37		0
THJU26		0
HUS28		0
HUS28-2		0
HHUS210-2		0
HHUS28-2		0
LUS28		0
SUL24		0
SUL26		0
SUR24		0
SUR26		0
THA422		0
THA426		0
THAC422		0
THAC426		0
THASL29		0
THASR29		0
TBE 4		2
		0
		0

Truss Connector Total List		
Manuf	Product	Qty
Simpson	LUS26	10
Simpson	THJA26	2
Simpson	TBE4	2

Hatch Legend	
	9-01-02

- EL EXTREMO IZQUIERDO DE LOS TRUSSES (VEA LOS PERFILES)

TODAS LAS DIMENSIONES PARA LAS TRUSSES SON DE FUERA DE LA MADERA (u.n.o.)

ESTABLECER LOS TRUSSES NIVELADAS CON LA ESTRUCTURA (u.n.o.)

- LEFT END OF TRUSS (SEE TRUSS PROFILES)

ALL ROOF TRUSS DIMENSIONS ARE FROM OUTSIDE EDGE OF STUD (u.n.o.)

SET ROOF TRUSSES FLUSH WITH FRAMING (u.n.o.)

WARNING: Trusses must be handled with care to prevent damage and injury.

This truss placement diagram is to be used only as an installation aid; it is not a structural diagram. These trusses are designed as individual building components to be incorporated into the building design at the the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing.

Professional advice should be sought regarding handling, installation, temporary and permanent bracing before erecting trusses. Temporary and permanent bracing is required during installation of trusses to prevent possible collapse.

For general guidance regarding bracing, consult "BCSI-06" available jointly from WTCA & TPI.

Premier Building Supply must be notified of any issues requiring a back charge prior to any work being done. Premier Building Supply reserves the right to use it's service staff in lieu of being back charged.

The diagram illustrates the roof truss placement for a building. It features a grid of trusses labeled C01 through C09 and B01. The trusses are spaced at 10'-00" intervals. The rafters are labeled A01 through A04 and V01 through V05. The diagram includes dimensions for the truss spacing (10'-00", 20'-00", 36'-00", 46'-00") and the overall roof dimensions (46'-00" x 59'-06"). The trusses are shown in yellow, and the rafters are shown in blue. The diagram also includes labels for the truss and rafter types (e.g., LUS26, THJA26, TBE4) and their quantities. The diagram is oriented with the trusses running horizontally and the rafters running vertically.

1 - SDWC 15600 REQUIRED AT ALL BEARING LOCATIONS (u.n.o.)
ALL TRUSS TO TRUSS CONNECTIONS = "NAILED" (u.n.o.)
1 - SDWC 15600 NECESARIO EN TODO LOS PUNTOS DE APOYO (u.n.o.)
TODAS LAS CONEXIONES DE TRUSS A TRUSS = "CLAVADAS " (u.n.o.)