

1 - SDWC 15600 REQUIRED AT ALL BEARING LOCATIONS (u.n.o.) ALL TRUSS TO TRUSS CONNECTIONS = 'NAILED" (u.n.o.) 46-00-00 - SDWC 15600 NECESARIO EN TODO LOS PUNTOS DE APOYO (u.n.o.) 10-00-00 36-00-00 TODAS LAS CONEXIONES DE TRUSS A TRUSS = 'CLAVADAS " (u.n.o.) **PB01** 1-04-08 PB01 2-00-002-00-002-00-00 LUS26 10-12 PB01 4-06-00 PB01 -.00-002-00-002-0 PB01 PB01 PB01 LUS28 PB01 FINESSS 4 C2  $\frac{1}{2}$ PB01 72 PB01 2-00-00 В1 Truss Connector Total List Qty Manuf Product **ALL PLATE HEIGHTS ARE 09-01-02** Simpson LUS26 5-00-00 20-00-00 10-00-00 Simpson LUS28 2 Simpson THJA26 2 46-00-00