


ONE-TIME-BUILD LICENSE AGREEMENT

NOTE: GOVERNING CODES &
GENERAL CONTRACTOR'S WRITTEN SPECIFICATIONS
TAKE PRIORITY OVER THESE PLANS.




FRONT ELEVATION

SCALE: 1/4" = 1'-0"



RIGHT ELEVATION
SCALE: 1/8" = 1'-0"



LEFT ELEVATION
SCALE: 1/8" = 1'-0"





REAR ELEVATION

CLAWHAMS
SHUT DOWN YOUR DOWN DOME AND YOUR ELEVATORS
DOWN DOME SHUT DOWN
LARGE REEF AND OFF TO WEST FOR CIRCLE
ALSO TURNED TO ONE




FRONT ELEVATION

SCALE: 1/4" = 1'-0"



RIGHT ELEVATION
SCALE 1/8" = 1'-0"

RIGHT ELEVATION
SCALE: 1/8" = 1'-0"



LEFT ELEVATION
SCALE 1/8" = 1'-0"

LEFT ELEVATION
SCALE: 1/8" = 1'-0"



180

100% PAYMENT IN ADVANCE
NO CREDIT CHECK
NO SECURITY DEPOSIT
NO FURNITURE DEPOSIT

3




BUILDER/CONTRACTOR IS RESPONSIBLE TO
CHECK ALL DIMENSIONS FOR ACCURACY
BETWEEN FLOORS, FOUNDATION, AND ELEVATIONS.
ALSO VERIFY ALL BEAM, HEADERS, PAD LOCATIONS,
AND COLUMN SIZES.

FRONT ELEVATION

1/8" = 1'-0"

NOTE:

ACTUAL ELEVATIONS MAY VARY FROM ARCHITECTURAL
DRAWINGS DUE TO TERRAIN, MATERIALS, PROBLEMS
WITH ELEVATION OR ARCHITECTURAL DRAWINGS AND
MAY VARY DUE TO AVAILABLE AVAILABILITY.




RIGHT ELEVATION

1/8" = 1'-0"



REAR ELEVATION

1/8" = 1'-0"



LEFT ELEVATION

1/8" = 1'-0"

SQU

LIV/919-1




BUILDER/CONTRACTOR IS RESPONSIBLE TO
CHECK ALL DIMENSIONS FOR ACCURACY
BETWEEN FLOORS, FOUNDATION, AND ELEVATIONS.
ALSO VERIFY ALL BEAM,-Headers, PAD LOCATIONS,
AND COLUMN SIZES.

FRONT ELEVATION

1/8" = 1'-0"

NOTE:
ACTUAL ELEVATIONS MAY VARY FROM ARCHITECTURAL
DRAWINGS DUE TO TERRAIN, SOIL CONDITIONS
PRINT ELEVATION IN ARCHITECTURAL DRAWING ARE
MAY VARY DUE TO MATERIALS AVAILABILITY



LEFT ELEVATION

1/8" = 1'-0"



REAR ELEVATION

1/8" = 1'-0"



RIGHT ELEVATION

1/8" = 1'-0"