CITY OF LEE'S SUMMIT

Development Services Department 220 SE Green Street Lee's Summit, MO 64063 (816)969-1200

OnlinePortal at DEVSERVICES.CITYOFLS.NET

Inspection Summary

Permit #: PRCOM20235681

Address: 3200 NE WILSHIRE DR, LEES SUMMIT, MO 64064

This work has been inspected and the inspection results noted below. Please schedule inspections once all corrective actions have been completed. Do not cover any work until approved.

Inspection: Outcome: Date:

All Rough Inspection - Khanh Nguyen Failed Friday, August 22, 2025

Commercial

Corrective Action Required:

1 Misc Interior shearwall:

-1st floor

Exterior wall sheathing nailing-OK

**Rough plumbing test pressure not holding

Corrective Action Required:

2 FIRST FLOOR -Corridor ceiling pre-rock OK

-Lobby/Mail area (1001) ceiling pre-rock OK

-Office (1002) ceiling pre-rock OK

-Shower wall pre-rock OK

**Correction:

-Install 4-stud pack under LVL beam

-Install studs aligned with floor trusses throughout

Corrective Action Required:

3 SECOND FLOOR -Corridor ceiling pre-rock OK

-Common area (2001) ceiling pre-rock OK

-Shower wall pre-rock OK

**Corrections for common area (2001) ceiling pre-rock:

- -Tie both trusses of girder together
- -Install 4-stud pack under LVL beam
- -Install studs aligned with floor trusses throughout

Corrective Action Required:

4 THIRD FLOOR

- -Shower wall pre-rock OK
- **Check all:
- -Sheathing continuous from subfloor to subfloor per E4/S501 for demising and stair wall
- -Close gap at top and bottom of the vertical fire blocking
- -Provide 7" oc pattern for GB at showers
- -Protect all penetrations of fire barrier walls (elevator and stairs) in floor space
- -Add studs directly above window king studs

| 201: |
|---|
| 202: -Provide truss repair. The submitted repair doesn't reflect the actual damaged truss -Broken bottom wall plate below panel |
| 204: |

203:205:

206:

207:

-Draft stop above shear wall

208:

- -Provide revised floor truss plan not matched with building layout
- -Double truss girder not fasten together
- -Have engineer look at truss support at angle hangers
- -Frame out wall for plumbing
- -Nail all hangers
- -Fc elevator wall membrane penetrations at hangers; Fc all gaps
- -Fb at top of wall at mechanical closet

Common area:

- -Protect drain line
- -Fc wall plate penetrations

Corridor restroom:

- -Nail all hangers
- -Install blockings for grab bars

209:

| -Fc floor penetration at dead space adjacent to shower -Frame around sprinkler above shower and fb as required -Nail corner studs in bedroom |
|--|
| 210: -Fire protect electrical box at demise wall |
| 211: |
| 213: -Draft stop above water closet |
| 212: |
| 214: |
| 215: |
| 216: -Add studs directly above window king studs |
| 217: -Add studs directly above window king studs |

Comments: