

# Development Services Department

220 SE Green Street Lee's Summit, MO 64063

(816) 969-1200 FAX (816) 969-1201

## Inspection Summary

---

Permit #:PRRES20180922, Building Permit - Residential  
Address: 500 NE WENONGA PL, LEES SUMMIT, MO 64064

---

This work has been inspected and the inspection results noted below. Please call for re-inspection once all corrective actions have been completed. Do not cover any work until approved.

---

Inspection:	Inspector:	Outcome:	Date:
<b>Gas Service Inspection - Residential</b>	Khanh Nguyen	Passed	Tuesday, October 09, 2018

<b>All Rough Inspection - Residential</b>	Khanh Nguyen	Failed	Tuesday, October 09, 2018
---	--------------	--------	---------------------------

### Corrective Action Required

1 Misc

#### FRAMING:

- Provide plan on site
- Redo piers outside. The two outer piers settled
- Fb wall space from soffit at front basement bedroom
- Nail garage portal wall sheathing per code; install 2" washers
- Anchor garage sill plate near dryer
- Install beam support under stoop roof load above garage
- Install security blocking for rear door 3 stud spaces out
- Fb wall space at closet/master shower from roof; Fb basement rear bedroom wall from ceiling furdow space
- Install 3 stud support for roof lvl beam near master bedroom door
- Nail all hangers at stair
- Header off cut joist at water heater b vent
- Anchor sill plate near service panel

#### MECHANICAL:

- Install b vent shield in attic
- Pan off return air space from front basement bedroom soffit; provide return air from front basement bedroom

#### ELECTRICAL:

- Protect wiring at bottom wall plate near range; in pantry ; at

master bedroom ceiling string light circuit  
-Provide rear wall receptacle spacing per code  
-Over filled 2-gang box outside master bedroom  
-Staple wiring min min 1.25" from nailing surface basement bath and outside bath  
-Securely fasten the SE cable within 12" of meter and service disconnect ; securely fasten all NM cable at maximum 4.5 ft interval, not just resting on framing  
-Complete cooktop circuit  
-Move smoke alarm outside the soffit and install alarm minimum 4 inches from soffit wall

**\*\*OK TO INSULATE**

**Electrical Service  
Inspection - Residential**

Khanh Nguyen      Passed

Tuesday, October 09, 2018

**Comments:**