CITY OF LEE'S SUMMIT

Development Services Department 220 SE Green Street Lee's Summit, MO 64063 (816)969-1200

DEVSERVICES.CITYOFLS.NET

Inspection Summary

Permit #: PRRES20201406

Address: 4701 NE SARATOGA CT, LEES SUMMIT, MO 64064

This work has been inspected and the inspection results noted below. Please schedule inspections once all corrective actions have been completed. Do not cover any work until approved.

Inspection: Inspector: Outcome: Date:

All Rough Inspection - Khanh Nguyen Failed Monday, September

Residential 14, 2020

Corrective Action Required:

1 Misc FRAMING:

- -Install vapor barrier on exterior wall sheathing
- -Portal brace walls sheathing sram shall be within 24" of mid-wall height and shall be blocked and nailed
- -Nail siding per code
- -Shim gap underneath IvI support studs at corner adjacent to slide door
- -Fb double stud wall vertically at ten ft or less interval; Fb north basement bathroom wall vertically per code
- -Fill in gap between joists at triple joist hangers above rear basement bathroom
- -Tempered glass windows required where within 24" of basement door
- -Insulate first, then solidblock all cantilevered joists above bearing wall; do same for joists under fireplace
- -Install double joist under front bedroom closet bearing wall per plan
- -Verify that's there are column pad underneath column

PLUMBING:

- -Install stud shoe for stud bored more than 60% at master bathroom
- -Strap exterior and interior bearing wall where bored more than 50%
- -Protect plumbing near electrical panel; in basement closet
- -Support pvc at 4 ft or less interval above NW basement bedroom
- -Waste stack clean out inside closet shall be accessible

-Complete gas piping

MECHANICAL:

- -Frame and fasten fireplace to framing
- -Connect ducting to front bathroom and basement bathroom fans
- -Pan off return air space from ceiling furdown above wet bar. No parallel electrical wiring inside return air space; seal return air space hole above wet bar near bathroom wall

ELECTRICAL:

- -Install a wall receptacle for foyer wall wider than 3 ft (foyer larger than 60 square ft)
- -Protect wiring at stair/kitchen wall on stair side
- -Securely fasten wiring within 12" of service panel
- -Clean off all gypsum splatter from interior of panel
- -Install a wall receptacle for wall wider than 2 ft in NW basement bedroom
- **UFER GROUNDING CONNECTION MUST BE ACCESSIBLE AT FINAL INSPECTION
- **OK TO INSULATE

Comments: