CITY OF LEE'S SUMMIT **Development Services Department** 220 SE Green Street Lee's Summit, MO 64063 (816)969-1200

DEVSERVICES.CITYOFLS.NET

Inspection Summary

Permit #: PRRES20210283

Address: 317 NW AMBERSHAM DR, LEES SUMMIT, MO 64081

This work has been inspected and the inspection results noted below. Please schedule inspections once all corrective actions have been completed. Do not cover any work until approved.

Inspection: Inspector: Outcome: Date:

All Rough Inspection -

Residential

Michael Harkins

Failed

Thursday, July 01, 2021

Partial Correction:

1 Misc GARAGE PORTAL FRAMING OK TO COVER **COVERED DECK TRUSSES OK TO COVER** FRONT PORCH TRUSSES OK TO COVER : ONLY THE ABOVE ITEMS INSPECTED:

SHEATHING REQUIRES NAILING PER CODE BEFORE INSTALLING HARDIE BOARD

SIDING

THIS HAS IS COVERED WITH TYVEK UNABLE TO VERIFY NAIL PATTERN BELOW

AREAS ARE NOT NAILED PER CODE

MASTER BEDROOM BOTH SIDES OF WINDOWS, BED # 2 / DINING ROOM AT DEAD SPACE, GREAT ROOMSE CORNER, FRONT DOOR, OFFICE CLOSET,

BASEMENT REAR WALL, SOUTH WALL

Tighten 5/8!anchor bolt garage portal frame

Provide anchor bolts within 12" of plate break garage north wall

Seal top plate penetration south wall garage

Fire block dead space mud room / refrigerator / range

Seal bottom plate at duct microwave, master bath, master closet

Seal top plate penetration doorbell in office

Provide straps CS-PF bracing method Foyer, Fireplace, covered deck, dining, master per plan

Seal top plate penetration foyer

Fire blocking fireplace

Provide 4 studs at GT bearing points per roof plan @ great room

Fire block dead spaces dining room

Seal top plate penetrations bed # 2

Seal bore in floor bath b# 2

Seal top & bottom plate penetrations powder room

Provide hangers per truss schedule master bed

Nail studs in corners of braced wall panels

Provide roof vent at covered deck per plan

Seal top plate penetrations master closet

Provide anchor bolts within 12" of plate break & end of plate at patio door

Seal top plate penetrations rec room / bed # 4

Provide anchor bolt at plate break & tighten anchor bolts bed #4

Provide 3 studs corner bed # 4 closet

Seal top plate penetration bath

Fire block bed # 3 above vanity

Provide vertical fire block every 10' bed #3 & bed 4 closet

Tighten anchor bolts throughout basement

Tyvek tape nail penetrations throughout

Install doors

Provide flashing above horizontal trim @ windows

Comments: