

TODAS LAS DIMENSIONES PARA LAS TRUSSES SON DE FUERA DE LA MADERA (u.n.o.)

ESTABLECER LOS TRUSSES NIVELADAS CON LA ESTRUCTURA (u.n.o.)

- LEFT END OF TRUSS (SEE TRUSS PROFILES)

ALL ROOF TRUSS DIMENSIONS ARE FROM OUTSIDE EDGE OF STUD (u.n.o.) SET ROOF TRUSSES FLUSH WITH FRAMING (u.n.o.)

WARNING: Trusses must be handled with care to prevent damage and injury.

This truss placement diagram is to be used only as Inis truss placement diagram is to be used only as an installation aid; it is not a structural diagram. These trusses are designed as individual building components to be incorporated into the building design at the the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing.

Professional advice should be sought regarding handling, installation, temporary and permanent bracing before erecting trusses. Temporary and permanent bracing is required during installation of trusses to prevent possible collapse.

For general guidance regarding bracing, consult "BCSI-06" available jointly from WTCA & TPI.

Premier Building Supply must be notified of any issues requiring a back charge prior to any work being done. Premier Building Supply reserves the right to use it's service staff in lieu of being back charged.



	HEEL HEIGHT: 6", 8"
TRUSS QUANTITY: 54 ROOF AREA: 1,899 GABLE AREA: 488	ROOF PITCH LEFT TO RIGHT: 8/12 SOFFIT DESIGNED FOR 12" O.H HEEL HEIGHT: 10"
HORIZONTAL OVERHANGS: 85	ALL CEILINGS ARE FLAT UNLESS OTHERWISE
HIP LINES: 0 RAKED OVERHANGS: 145 RIDGE LINES: 62	ROTATE ATTIC ACCESS TO ALIGN WITH TRUSS DIRECTION.
VALLEY LINES: 48	

ROOF PITCH FRONT TO BACK: 4/12, 6/12

SEE PLACEMENT PLAN FOR ADDITIONAL

SOFFIT DESIGNED FOR 12" O.H

SECOND FLOOR