

- EL EXTREMO IZQUIERDO DE LOS TRUSSES (VEA LOS PERFILES)

TODAS LAS DIMENSIONES PARA LAS TRUSSES SON DE FUERA DE LA MADERA $({\rm u.n.o.})$

ESTABLECER LOS TRUSSES NIVELADAS CON LA ESTRUCTURA (u.n.o.)

- LEFT END OF TRUSS (SEE TRUSS PROFILES)

ALL ROOF TRUSS DIMENSIONS ARE FROM OUTSIDE EDGE OF STUD (u.n.o.) SET ROOF TRUSSES FLUSH WITH FRAMING (u.n.o.)

WARNING: Trusses must be handled with care to prevent damage and injury.

This truss placement diagram is to be used only as an installation aid; it is not a structural diagram. These trusses are designed as individual building components to be incorporated into the building design at the the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing.

Professional advice should be sought regarding handling, installation, temporary and permanent bracing before erecting trusses. Temporary and permanent bracing is required during installation of trusses to prevent possible collapse.

For general guidance regarding bracing, consult "BCSI-06" available jointly from WTCA & TPI.

Premier Building Supply must be notified of any issues requiring a back charge prior to any work being done. Premier Building Supply reserves the right to use it's service staff in lieu of being back charged.

FIRST FLOOR

																1 - SDWC 15600 REQUIRED AT ALL BEARING LOCATIONS (u.n.o.) ALL TRUSS TO TRUSS CONNECTIONS = 'NAILED" (u.n.o.)								
																	1 - SDWC 15600 NECESARIO EN TODO LOS PUNTOS DE APOYO (u.n.o.) TODAS LAS CONEXIONES DE TRUSS A TRUSS = 'CLAVADAS " (u.n.o.)							
																							HANGER SCHEDULE	QUANTI TY
																							LUS24 LUS26	3
																							HUS26	0
																							HHUS26-2	0
																							HGUS26-2	0
																							HGUS28-2 THJA26	0
																							TJC37	0
																							THJU26	0
																							HUS28 HUS28-2	0
36-00-00																	HUS28-2 HHUS210-2	0						
		1-11-04	∠-∪U-0Q	∠-00-0Q	¥-00-00	∠-UU-0Q	<u></u> -υυ-00	∠-UU-0Q	<u>∠-00-00</u>	∠-UU-0Q	<u>∠-00-00</u>	<u>∠-00-00</u>	∠-UU-0(¥-00-00	∠-υυ-0Q	<u></u>	-00-002	-00-00	1-11-04				HHUS28-2	0
				\																	1	1	LUS28	0
																							SUL24 SUL26	0
							E4	22-02-04 E4															SUR24	0
																							SUR26	0
																							THA422	0
																							THA426 THAC422	0
																							THAC426	0
																					29-00-00		THASL29	0
						E4																	THASR29 TBE4	0
	Ш	E4	E4	E4	E4				E4	E5	E5	E6	Е6 Е	E6	E6	E6	E6	E6	E		29-0		TBE4 TBE6 LGT3-	0
8																							LGT3- SDS2.5	0
39-00-00 37-00-00		-					\wedge														-	39-00-00		
39-0	V1								R1													39-(
		V2	V3	V4		/		2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	D3	87 67	V10													
								5-00-0 <u>0</u>	D3															
		2						-00-0 <u>0</u>	D3															
						00-00			D3															
						00-002-1			D3															
						0-00-0			D3			+ $+$ $+$ $+$ $+$ $+$ $+$ $+$ $+$ $+$								8-00-00				
		*						002-00	D3											~				
								-00-	D2															
2-00-00			► ► ► D1																		2-00-00			
		<u></u>	7-01-0	00				13-08	8-00			_	5-04-	00 .	Ļ	ę	9-11-00							
	١									36-0	0-00									ł				
									SE		id fl	_00F	7											
																ROOF PITCH FRONT TO BACK: 4/12, 6/12 SOFFIT DESIGNED FOR 12" O.H								
																HEEL HEIGHT: 6", 8"								
		ROOF PITCH LEFT														12								
								I	ROOI	F AR	EA:	1,8	399	54		SOFFIT DESIGNED FOR 12" O.H HEEL HEIGHT: 10"								
	GABLE AREA: 488 HORIZONTAL OVERHANGS: A												ALL CEILINGS ARE FLAT UNLESS OTHERWISE											
	85 HIP LINES: 0											NOTED												
												- HANC	GS:	145	5	ROTATE ATTIC ACCESS TO ALIGN WITH TRUSS								

RAKED OVERHANGS: 145

RIDGE LINES: 62 VALLEY LINES: 48 DIRECTION. SEE PLACEMENT PLAN FOR ADDITIONAL