DO NOT CUT, DRILL, NOTCH, OR OTHERWISE DAMAGE TRUSSES. Contact your BFS Representative for assistance PRIOR TO modifying any truss. Espanol - (NO CORTE, PERFORE, HAGA MUESCAS O DANE DE CUALQUIER OTRA MANERA LAS TRUSSES (CERCHAS DE MADERA). Contacte a su representante de BFS para asistencia ANTES de

realizar cualquier modification.)

1. This Truss Placement Diagram is intended to serve as a guide for truss installation. This Diagram has been prepared by a Truss Technician and is not an engineered drawing.

2. The responsibilities of the Owner, Building

 The responsibilities of the Owner, Building Designer, Contractor, Truss Designer, and Truss Manufacturer shall be as defined by the TPI 1 National Standard.

 The wood components shown on this diagram are to be used in dry service (moisture content-19%) and non-toxic environmental applications. The metal plates and hangers are galvanized to the G60 Standard unless noted otherwise.

 Refer to the Truss Design Drawings for specific information about each individual truss

design.
5. The Truss Technician shall provide Truss-to-Truss Connection Requirements. Any special or other connection shall be the responsibility of the Building Designer.

6. The Truss Placement Diagram and Truss Design Drawings are the property of Builders FirstSource and may not be reused or reproduced in part or in total under any circumstances without prior written

7. In some cases, field framing may be required to achieve the final appearance shown on the Construction Documents.

8. Field framing, including valley rafters, installed over roof trusses shall have a knee brace from the rafter to the truss top chord at intervals of 48" on center (O.C.) or less. Stagger knee braces from adjacent rafters such that the load is distributed uniformly over multiple truss locations and not concentrated at one location or along one truss.

3. Truss Top Chords shall be fully sheathed or have lateral bracing (purlins) spaced at 24" O.C. or less. Truss Bottom Chord Bracing shall not exceed the maximum shown on the Truss Design Drawing. Field framed bottom chord floor or ceiling attachments shall be spaced at 24" O.C. or less. Proper Bracing prevents buckling of individual truss members due to design loads.

10. This Placement Diagram is based upon the supporting structure being structurally adequate, dimensionally correct, square, plumb, and level to adequately support the trusses. The foundation design, structural member sizing, load transfer, bearing conditions, and the structure's compliance with the applicable building code are the responsibility of the

Owner, Building Designer, and Contractor.

11. If Piggyback Trusses are included in this project, refer to the Mitek Piggyback Connection Detail applicable for the project details and wind load category.

12. The Contractor shall follow the SBCA TTB

12. The Contractor snail tollow the SBCA FIB Partition Separation Prevention and Solutions for truss attachment to non-load bearing walls and carefully complete these details to avoid gypsum wall board related issues. WARNING:

TRUSSES MUST BE BRACED DURING
INSTALLATION. FAILURE TO DO SO MAY
RESULT IN INJURY OR DEATH. Espanol (TRUSSES (CERCHAS) DEBERAN TENER UN
SOPORTE DURANTE LA INSTALACION. NO
HACERLO PODRIA RESULTAR EN LESIONES O
MUERTE.)

1. Trusses shall be installed in a safe manner

neeting all code, local, OSHA, TPI, and BCSI Specifications. Failure to follow these specifications may result in injury or death.

 Buildings under construction are vulnerable to high winds and present a possible safety hazard. The Contractor is responsible for recognizing adverse weather conditions and shall take appropriate action to prevent injury or

3. BCSI INSTRUCTIONS SHALL BE FOLLOWED: BCSI-B1 = Safe Truss Handling and Installation BCSI-B2 = Installation and Temporary Restraint BCSI-B3 = Permanent Restraint BCSI-B4 = Safe Construction Loading

BCSI-B4 = Safe Construction Loading BCSI-B5 = Truss Damage and Modification Guidelines

BCSI-B7 = Floor Truss Installation BCSI-B8 = Toe-Nailed Connections BCSI-B9 = Multi-Ply Girders

BCSI-B9 = Multi-Ply Girders BCSI-B10 = Post Frame Truss Installation BCSI-B11 = Fall Protection

4. Follow TPI Requirements for Long Span Trusses (>60').

RESIDENTIAL ENGINEERING SERVICES, LLC SHOP DRAWINGS/SUBMITTAL REVIEW

SUBMITTAL WAS REVIEWED FOR DESIGN CONFORMITY AND GENERAL CONFORMANCE TO CONTRACT DOCUMENTS ONLY. THE CONTRACTOR IS RESPONSIBLE FOR CONFIRMING AND CORRELATING DIMENSIONS AT JOBSITE FOR TOLERANCE, CLEARANCE, QUANTITIES, FABRICATION, COORDINATION OF HIS OR HER WORK WITH OTHER TRADES, AND FULL COMPLIANCE WITH

STATUS:

APPROVED

03.08.2021

REVIEWED BY:

BH

ENGINEER, RESIDENTIAL ENGINEERING SERVICES, LLC

FRONT TO BACK PITCH: 6/12 SOFFIT DESIGNED FOR: 10-1/2" HEEL HEIGHT: 7-5/8"

SIDE TO SIDE PITCH: 8/12 SOFFIT DESIGNED FOR: 10-1/2" HEEL HEIGHT: 10-1/4"


BOX VAULTS/COFFERS AT BEDROOM #1, GREAT ROOM, KITCHEN, & FOYER


WALL HEIGHT: 9'-1-1/8" EXTERIOR WALLS: 2X4

UNLESS NOTED OTHERWISE SEE LAYOUT FOR INFORMATION DIFFERENT FROM ABOVE STANDARD

> Roof Plane Hip Lines,155.98 Horizontal Overhang Lines,218.36 Raked Overhang Lines,73.46 Ridge Lines1,49.38 Roof Area,3178.09 Valley Lines,63.94

HNGR	QTY	CARRIED MBR		
HUS26	10	B3-B5		
H2.5A	40	TRUSS TO BEAM/WALL TIE DOWN		
SDWC15600	100	TRUSS TO WALL TIE DOWN		





DESIGN LOADS:

25 PSF TCLL 10 PSF TCDL 10 PSF BCDL

AT THE JOBSTIE. TEMPORARY AND PERMANEUT BRACING FOR HOLDING SPECIAL BE DESIGNED AND EN PLAND FOR RESISTING LATERAL FORCES SHALL BE DESIGNED AND EN BY OTHERS. NO LOADS OTHER THAN THE INTALLERS ARE TO BE APPLIED ESE UNTIL AFTER ALL BRACING AND FASTENING IS COMPLETED. AT OTTIME CONCENTRATED LOADS REATER THAN DESIGN LOADS BE APPLIED TO THE STALL TRUSS TO FRAMING CONNECTIONS ARE RECOMMENDATIONS ONLY. ED TO BE SPECIFIED BY THE BUILDING DESIGNER. TRUSSES ARE CAPABLE OF

BuildersFirstSource



2684960	Summit Homes - Manor At Stoney Creek #93	4412 SW Alabaster Circle	Lee's Summit, MO	Scott Clevenger	2/26/2021
JOB No.	DESCRIPTION	JOB ADDRESS	KTIO	DESIGNER	DATE

ROOF TRUSS LAYOUT

1 of 1

03/09/2021