DO NOT CUT. DRILL. NOTCH. OR OTHERWISE DAMAGE TRUSSES. Contact your BFS Representative for assistance PRIOR TO modifying any truss. Espanol - (NO CORTE, PERFORE, HAGA MUESCAS O DANE DE CUALQUIER OTRA MANERA LAS TRUSSES (CERCHAS DE MADERA). Contacte a su representante de BFS para asistencia ANTES de

3. The wood components shown on this diagram are to be used in dry service (moisture galvanized to the G60 Standard unless noted

4. Refer to the Truss Design Drawings for

design. 5. The Truss Technician shall provide Truss-to-

6. The Truss Placement Diagram and Truss Design Drawings are the property of Builders FirstSource and may not be reused or reproduced in part or in total under any circumstances without prior written

to achieve the final appearance shown on the

8. Field framing, including valley rafters, installed over roof trusses shall have a knee brace from the rafter to the truss top chord at

9. Truss Top Chords shall be fully sheathed or have lateral bracing (purlins) spaced at 24" O.C. or less. Truss Bottom Chord Bracing shall not Drawing. Field framed bottom chord floor or

to adequately support the trusses. The foundation design, structural member sizing, load transfer, bearing conditions, and the structure's compliance with the applicable building code are the responsibility of the

load category.

12. The Contractor shall follow the SBCA TTB

TRUSSES MUST BE BRACED DURING INSTALLATION. FAILURE TO DO SO MAY RESULT IN INJURY OR DEATH. Espanol -(TRUSSES (CERCHAS) DEBERAN TENER UN SOPORTE DURANTE LA INSTALACION, NO MUERTE.)

1. Trusses shall be installed in a safe manner Specifications. Failure to follow these

2. Buildings under construction are vulnerable to high winds and present a possible safety hazard. The Contractor is responsible for recognizing adverse weather conditions and


3. BCSI INSTRUCTIONS SHALL BE FOLLOWED: BCSI-B1 = Safe Truss Handling and Installation BCSI-B2 = Installation and Temporary Restraint

BCSI-B3 = Permanent Restraint BCSI-B4 = Safe Construction Loading

BCSI-B5 = Truss Damage and Modification Guidelines BCSI-B7 = Floor Truss Installation

BCSI-B8 = Toe-Nailed Connections BCSI-B9 = Multi-Ply Girders

BCSI-B11 = Fall Protection






Diagram has been prepared by a Truss Technician and is not an engineered drawing. 2. The responsibilities of the Owner, Building Designer, Contractor, Truss Designer, and Truss Manufacturer shall be as defined by the TPI 1 National Standard.

content<19%) and non-toxic environmental applications. The metal plates and hangers are

Truss Connection Requirements. Any special or other connection shall be the responsibility of the Building Designer.

7. In some cases, field framing may be required

intervals of 48" on center (O.C.) or less. Stagger knee braces from adjacent rafters such that the load is distributed uniformly over multiple truss locations and not concentrated at one location or along one truss.

exceed the maximum shown on the Truss Design celling attachments shall be spaced at 24" O.C. or less. Proper Bracing prevents buckling of individual truss members due to design loads.

This Placement Diagram is based upon the supporting structure being structurally adequate, dimensionally correct, square, plumb, and level

Owner, Building Designer, and Contractor.

11. If Piggyback Trusses are included in this project, refer to the Mitek Piggyback Connection
Detail applicable for the project details and wind

Partition Separation Prevention and Solutions for truss attachment to non-load bearing walls and carefully complete these details to avoid gypsum wall board related issues.


WARNING: HACERLO PODRIA RESULTAR EN LESIONES O

meeting all code, local, OSHA, TPI, and BCSI specifications may result in injury or death.

shall take appropriate action to prevent injury or

BCSI-B10 = Post Frame Truss Installation

4. Follow TPI Requirements for Long Span Trusses (>60').



DESIGN LOADS:

25 PSF TCLL 20 PSF TCDL 10 PSF BCDL

INSTALLATION
R HOLDING
SIGNED AND
O BE APPLIED
O. AT NO TIME
VLIED TO THE
ATTONS ONLY
E CAPABLE OF

WWW.BLDR. Builders FirstSourc



7					
2745269	Summit Homes - Woodside Ridge #25	2113 NW Ashurst Drive	Lee's Summit, MO	Scott Clevenger	4/9/2021
JOB No.	DESCRIPTION	JOB ADDRESS	YTIO	DESIGNER	DATE
ı	_	\sim	\sim	_	

ROOF TRUSS LAYOUT PAGE

1 of 1