


November 18, 2021

Summit Homes
 120 SE 30th St.
 Lee's Summit, MO 64082

RE: Field Issue of over-bored hole in floor joist for Lot #8 Hawthorne Ridge – 2934 Arboridge Dr. Lee's Summit, MO 64081 – Permit # PRRES20212324

This letter addresses the over-bored hole for DWV for bath #2 for Lot#8 Hawthorne Ridge.

- Hole is approximately 4" in diameter.
- Hole is approximately 2" from bottom of floor joist and approximately 2' from steel beam support at unfinished storage.
- Floor joists are Douglas Fir Larch #2 2x10 at 16" oc double every other and span approximately 16' with standard dead=10 psf and live=40 psf loads.
- Install a 24" length of CS-16 strap centered beneath the overbored hole.
- Install with fasteners per manufacturer's specs.



For SI: 1 inch = 25.4 mm.

FIGURE R502.8 CUTTING, NOTCHING AND DRILLING

R502.8.1 Sawn lumber.

Notches in solid lumber joists, rafters and beams shall not exceed one-sixth of the depth of the member, shall not be longer than one-third of the depth of the member and shall not be located in the middle one-third of the span. Notches at the ends of the member shall not exceed one-fourth the depth of the member. The tension side of members 4 inches (102 mm) or greater in nominal thickness shall not be notched except at the ends of the members. The diameter of holes bored or cut into members shall not exceed one-third the depth of the member. Holes shall not be closer than 2 inches (51 mm) to the top or bottom of the member, or to any other hole located in the member. Where the member is notched, the hole shall not be closer than 2 inches (51 mm) to the notch.

Model No.	Total L	Ga.	DF/SP		SPF/HF		Allowable Tension Loads (160)	Code Ref.
			Fasteners	End Length	Fasteners	End Length		
CMST12	40'	12	(74) 16d	33"	(84) 16d	38"	9,215	14, L3, FL
			(86) 10d	39"	(96) 10d	44"	9,215	
CMST14	52 1/2'	14	(56) 16d	26"	(66) 16d	30"	6,490	
			(66) 10d	30"	(76) 10d	34"	6,490	
CMSTC16	54'	16	(50) 16d sinker	20"	(58) 16d sinker	25"	4,585	
CS14	100'	14	(26) 10d	15"	(30) 10d	16"	2,490	
			(30) 8d	16"	(36) 8d	19"	2,490	
CS16	150'	16	(20) 10d	11"	(22) 10d	13"	1,705	
			(22) 8d	13"	(26) 8d	14"	1,705	
CS18	200'	18	(16) 10d	9"	(18) 10d	11"	1,370	
			(18) 8d	11"	(22) 8d	12"	1,370	
CS20	250'	20	(12) 10d	6"	(14) 10d	9"	1,030	
			(14) 8d	9"	(16) 8d	9"	1,030	
CS22	300'	22	(10) 10d	7"	(12) 10d	7"	845	
			(12) 8d	7"	(14) 8d	8"	845	

1. Fastener quantities and end lengths are calculated using an increase for wind or seismic loading.
 2. Use half of the required nails in each member being connected to achieve the listed loads.
 3. Calculate the connector value for a reduced number of nails as follows:

Sincerely,



Bradley Huxol, PE

