3. LOADING TO BE 40 PSF LL - 15 PSF DL

400 MARSHVIEW DRIVE SUN PRAIRIE, WI 53590 1-800-879-7123 1-608-834-2253

- INSTALLATION OF EWP PRODUCTS.
- PRODUCT.
- PLACEMENT PLAN. IT IS TO BE REVIEWED BY THE ENGINEER OF RECORD AND MUST MEET HIS/HER APPROVAL PRIOR TO INSTALLATION OF OUR PRODUCT.
- . THIS DOCUMENT IS NOT TO BE USED AS A REPLACEMENT FOR YOUR ORIGINAL STRUCTURAL PLANS.
- 5. LAYOUT, QUANTITY AND LENGTH TO BE VERIFIED BY CONTRACTOR.
- 6. IF WALLS ARE SPECIFIED IN THIS QUOTE, CONTRACTOR MUST VERIFY ALL DIMENSIONS AND ROUGH OPENING SIZES PRIOR TO CONSTRUCTION OF WALL. ROUGH OPENING SIZES ARE ESTIMATES ONLY. TALL WALL IS DESIGNED FOR VERTICAL LOADS AND DIRECT WIND LOADS ONLY. INLINE LATERAL BRACING OF THE BUILDING DIAPHRAGM IS TO BE ACCOUNTED FOR BY THE BUILDING DESIGNER/ENGINEER.

Ground F	loor						
Joist							
Label	Description	Width	Depth	Qty	Plies	Pcs	Leng
J14	LPI 20 Plus	2.5	9.5			2	48-0
J13	LPI 20 Plus	2.5	9.5			2	46-0
J12	LPI 20 Plus	2.5	9.5			2	42-0
J11	LPI 20 Plus	2.5	9.5			4	38-0-
J1	LPI 20 Plus	2.5	9.5			10	32-0-
J2	LPI 20 Plus	2.5	9.5			3	30-0-
J16	LPI 20 Plus	2.5	9.5			8	28-0-
J15	LPI 20 Plus	2.5	9.5			3	24-0
J9	LPI 20 Plus	2.5	9.5			8	18-0-
J5	LPI 20 Plus	2.5	9.5	1	2	2	18-0
J8	LPI 20 Plus	2.5	9.5			2	16-0
J7	LPI 20 Plus	2.5	9.5			8	14-0
J10	LPI 20 Plus	2.5	9.5			2	10-0-
J6	LPI 20 Plus	2.5	9.5			3	8-0-
J4	LPI 20 Plus	2.5	9.5	1	2	2	8-0-
Blocking		1	,				
Label	Description	Width	Depth	Qty	Plies	Pcs	Leng
BLK1	LPI 20 Plus	2.5	9.5			88	2-0-
Rim Board	b						
Label	Description	Width	Depth	Qty	Plies	Pcs	Leng [.]
R1	LP APA Rated OSB 1.125 X 9.5	1.125	9.5			20	12-0
LVL/LSL			,				
Label	Description	Width	Depth	Qty	Plies	Pcs	Leng
FB4	LP-LVL 2900Fb-2.0E	1.75	9.5	1	2	2	20-0
FB3	LP-LVL 2900Fb-2.0E	1.75	9.5	3	2	6	14-0
FB2	LP-LVL 2900Fb-2.0E	1.75	9.5	1	2	2	8-0-
FB1	LP-LVL 2900Fb-2.0E	1.75	9.5	1	2	2	6-0-



CONFORMANCE WITH REFERENCED PLAN





/ FARMS CIR

- SUMMIT VIEW I

SW

LOT 3208


0


This placement plan is to be used as an installation guide only. It is meant to be used in conjunction with the manufacturers installation guide, the architectural and structural drawings, and not to replace them.


A1 LP SOLID START RIM BOARD

SOLID RIM AS STARTER JOIST with Ladder Blocking Fasten rim board to each floor I-Joist using one 8d nail or 10d box nail per flange

lateral support as required. Use LP I-Joist, LP LVL, LP LSL, or LP Rim Board as blocking









FIRST FLOOR JOIST PLACEMENT PLAN LOT 119 - SUMMIT VIEW FARMS 3208 SW SADDLEBRED CIR

TL21063ATH

Provide blocking for





2. ALL BLOCKING PER STRUCTURAL PLAN

AMERHART

ADDITIONAL NOTES

- . ALWAYS READ PRODUCT BROCHURE BEFORE
- 2. REFER TO HOLE CHARTS PRIOR TO DRILLING
- 3. THIS DOCUMENT IS INTENDED SOLEY AS A