20300 W 207TH PREMIER BUILDING SUPPLY OF KANSAS CITY Phone: 913.686.1812 www.premierbuildingsuppl y.com Clover & Hive Job Name: **Emerald Townhome** 2002/2004/2006/2008 SW Holdbrooks Dr Kyle Clifford

6/29/2023 | P230318 | 1/4" = 1' ROOF TRUSS PLACEMENT DIAGRAM

Angela Justus

TRUSS QUANTITY GABLE AREA

HORIZONTAL OVERHANG LINES

SQUARE FOOTAGE IS ESTIMATED. CONTRACTOR/FRAMER VERIFICATION

RAKED OVERHANG LINES

HIP LINES

RIDGE LINES ROOF AREA

VALLEY LINES

REQUIRED.

911

415 158

5,815

102

RELEASE FOR CONSTRUCTION AS NOTED FOR PLAN REVIEW DEVELOPMENT SERVICES LEE'S SUMMIT, MISSOURI 09/26/2023

25-11-0

1 - SDWC 15600 REQUIRED AT ALL BEARING LOCATIONS (u.n.o.) ALL TRUSS TO TRUSS CONNECTIONS = 'NAILED" (u.n.o.)

- SDWC 15600 NECESARIO EN TODO LOS PUNTOS DE APOYO (u.n.o.) TODAS LAS CONEXIONES DE TRUSS A TRUSS = 'CLAVADAS " (u.n.o.)

104-0-0 25-10-0 25-11-0

ODD SPACING ODD SPACING V8 1-0-0 1-0-0 G1 G1 6-0-0 6-0-0 6-0-0 20-0-0 6-0-0 APPLY SCAB MATERIAL TO TRUSS. SEE STUDS PUSHED THRU TOP STUDS PUSHED THRU TOP STUDS PUSHED THRU TOP PLATES @ GIRDER BEARING PLATES @ GIRDER BEARING PLATES @ GIRDER BEARING DRAWINGS FOR ADDITIONAL 104-0-0 14-11-0 6-0-0 5-0-0 14-11-0 5-11-0 5-0-0 14-11-0 5-0-0 5-11-0 14-11-0 5-0-0 6-0-0

25-10-0

- EL EXTREMO IZQUIERDO DE LOS TRUSSES (VEA LOS PERFILES)

TODAS LAS DIMENSIONES PARA LAS TRUSSES SON DE FUERA DE LA MADERA

ESTABLECER LOS TRUSSES NIVELADAS CON LA ESTRUCTURA (u.n.o.)

- LEFT END OF TRUSS (SEE TRUSS PROFILES)

ALL ROOF TRUSS DIMENSIONS ARE FROM OUTSIDE EDGE OF STUD (u.n.o.) SET ROOF TRUSSES FLUSH WITH FRAMING (u.n.o.)

WARNING: Trusses must be handled with care to prevent damage and injury.

Professional advice should be sought regarding handling, installation, temporary and permanent bracing before erecting trusses. Temporary and permanent bracing is required during installation of trusses to prevent possible collapse.

Premier Building Supply must be notified of any issues requiring a back charge prior to any work being done. Premier Building Supply reserves the right to use it's service staff in lieu of being back charged.

This truss placement diagram is to be used only as an installation aid; it is not a structural diagram. These trusses are designed as individual building components to be incorporated into the building design at the the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing.

For general guidance regarding bracing, consult "BCSI-06" available jointly from WTCA & TPI.

ROOF PITCH FRONT TO BACK: 4/12 & 5/12 SOFFIT DESIGNED FOR 12" O.H HEEL HEIGHT: 8 1/4" - 7 3/16"

104-0-0

ROOF PITCH LEFT TO RIGHT: 8/12 SOFFIT DESIGNED FOR 12" O.H HEEL HEIGHT: 11 3/8"

TYPICAL WALL HEIGHT: 8-1-2





HANGER SCHEDULE	QUANTITY
HHUS28-2	21
SDWC 15600	250