20300 W 207TH St Spring Hill, KS 66083 PREMIER BUILDING SUPPLY OF KANSAS CITY www.premierbuildingsupply.com

Clayton Properties Basswood - Farmhouse

3820 SW Ravensgate Place


Kyle Clifford

Dereck Cooper

P240300 3/16" = 1'

ROOF TRUSS PLACEMENT DIAGRAM

RELEASE FOR CONSTRUCTION **AS NOTED ON PLANS REVIEW DEVELOPMENT SERVICES** LEE'S SUMMIT, MISSOURI 04/19/2024 3:51:47



- EL EXTREMO IZQUIERDO DE LOS TRUSSES (VEA LOS PERFILES)

TODAS LAS DIMENSIONES PARA LAS TRUSSES SON DE FUERA DE LA MADERA

ESTABLECER LOS TRUSSES NIVELADAS CON LA ESTRUCTURA (u.n.o.)

- LEFT END OF TRUSS (SEE TRUSS PROFILES)

ALL ROOF TRUSS DIMENSIONS ARE FROM OUTSIDE EDGE OF STUD (u.n.o.) SET ROOF TRUSSES FLUSH WITH FRAMING (u.n.o.)

WARNING: Trusses must be handled with care to prevent damage and injury.

This truss placement diagram is to be used only as Inis truss placement diagram is to be used only as an installation aid; it is not a structural diagram. These trusses are designed as individual building components to be incorporated into the building design at the the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing.

Professional advice should be sought regarding handling, installation, temporary and permanent bracing before erecting trusses. Temporary and permanent bracing is required during installation of trusses to prevent possible collapse.

For general guidance regarding bracing, consult "BCSI-06" available jointly from WTCA & TPI.

Premier Building Supply must be notified of any issues requiring a back charge prior to any work being done. Premier Building Supply reserves the right to use it's service staff in lieu of being back charged.



ROOF PITCH FRONT TO BACK: 4/12, 6/12 SOFFIT DESIGNED FOR 12" O.H HEEL HEIGHT: 6", 8"

ROOF PITCH LEFT TO RIGHT: 8/12 SOFFIT DESIGNED FOR 12" O.H HEEL HEIGHT: 10"

TRUSS QUANTITY: 54

HORIZONTAL OVERHANGS: 85

RAKED OVERHANGS: 145

ROOF AREA: 1,899

GABLE AREA: 488

RIDGE LINES: 62

VALLEY LINES: 48

HIP LINES: 0

ALL CEILINGS ARE FLAT UNLESS OTHERWISE NOTED

ROTATE ATTIC ACCESS TO ALIGN WITH TRUSS DIRECTION.

1 - SDWC 15600 REQUIRED AT ALL BEARING LOCATIONS (u.n.o.)

ALL TRUSS TO TRUSS CONNECTIONS = 'NAILED" (u.n.o.)

- SDWC 15600 NECESARIO EN TODO LOS PUNTOS DE APOYO (u.n.o.)

TODAS LAS CONEXIONES DE TRUSS A TRUSS = 'CLAVADAS " (u.n.o.)

HANGER

LUS24 LUS26

HUS26

HHUS26-2 HGUS26-2

HGUS28-2

THJA26

TJC37

THJU26

HUS28

HUS28-2

HHUS210-2 HHUS28-2

LUS28

SUL24

SUL26

SUR24

SUR26

THA422

THA426

THAC422

THAC426

THASL29

THASR29

TBE4

TBE6

QUANTITY

0

0

0

0

0

0

0

0

0

0 0

0

0

0

0

0 0

0

0

0

0

0 0

0

0

SEE PLACEMENT PLAN FOR ADDITIONAL INFORMATION